

Unless specific design elements are noted on the order form or at the time of template, the Standard Design Elements listed below shall be implemented in the production of the countertop.

- **Edge overhang:** 1-1/2" overhang of cabinet at non-seating areas
- **Seating area overhang:** 10" overhang (Natural Stone) and 12" overhang (Quartz). Unless otherwise specifically indicated or instructed on a quote request or order drawing, when cabinets are vaguely specified to have a seating area, the backside of the cabinet is generally assumed as the "seating area" by default. If the dealer/designer would like this changed, please specifically indicate on the job drawing which sides of the cabinets that are to be designated as the "seating areas". Dealer must verify that the seating area overhangs are correct, on the CAD drawing, at the time of Dealer Signoff.
- **Overhang steel supports (brackets):** If requested at time of ordering or template measure, at an additional charge, overhang steel supports can be installed at required locations. These steel supports shall be placed 36" on center, and in most scenarios, a minimum of 2 supports are required per top.
- **Edge profile default:** Any edge not listed or listed as TBD (To Be Determined) will default to Square Eased until Dealer changes in writing or Homeowner specifies at template measure in writing. Dealer must verify edge is correct, on the CAD drawing, at the time of Dealer Signoff.
- **Radius of outside corners (open ends):** 3/4"
- **Radius of inside corners:** 3-1/4" (minimum)
- **Undermount sink cutout:** Default = Overhang Mount. As a standard, Wolf Home Products fabricates all sinks with an Overhang Mount. In the event that a manufacture doesn't specify an overhang mount, and Wolf Home Products does not have a confirmed working overhang mount in our CAD sink library, the countertop will be fabricated with the manufacturer's suggested mounting option. Please insure any accessories for the customer's sink will work with this mounting method. See the diagram for an example of the Overhang Mount.
- **Backsplash:** 4" height - 3cm thickness
- **Seam locations:** Seam locations are at Wolf Home Products discretion.
 - o Seams not allowed over unsupported areas such as dishwashers, etc.
 - o Typically L-shaped, U-shaped, (etc.) tops will have seams and veining patterns typically change directions at corner seams.
 - o Long, wall to wall straight tops, typically over 96", may require a seam to prevent binding and breakage.
 - o Depending on the type, strength, and size of the piece behind the backside of a farm sink, slide in range, etc., seams typically placed on each side of that piece of stone behind the farm sink, slide in range, etc. As a general guideline, Wolf Home Products typically places seams in this situation as follows:
 - Granite: If the piece is less than 16" in depth
 - Quartz: If the piece is less than 5" in depth

